



How do I update my Pixbee watch Firmware? How often are updates required?

We suggest you update your Pixbee watch Firmware when you first set up your Pixbee and periodically check if further updates are required. Your Pixbee will need to be connected up to a WiFi or cellular connection to update.

To update the firmware on the Pixbee Video Smart Watch, please follow the below steps:

1. Swipe from right to left on the Pixbee watch screen 7 times. This will take you to the 'More' screen.
2. Swipe up until you see 'Update' appear in the options.
3. Press 'Update' to check if there are any Firmware updates. Press the arrow in the middle of the screen to initiate the Firmware update.
4. Once the Firmware update has downloaded and you have pressed the arrow your Pixbee watch will re-start and update its Firmware and Voila, you're done!

Please contact info@pixbee.com.au if you have any questions.